

## **Standard Door Closer Hole Pattern Chart (ANSI/BHMA A156.4)**

### **Regular Arm / Top Jamb (Pull Side)**

<b>Component</b>	<b>Hole Count</b>	<b>Hole Spacing</b>
Closer Body	4	1-1/2" x 3-1/4"
Arm Shoe	2	1-1/4" apart
Offset from Frame Rabbet -		2-1/4"

### **Parallel Arm (Push Side)**

<b>Component</b>	<b>Hole Count</b>	<b>Hole Spacing</b>
Closer Body	4	1-1/2" x 3-1/4"
Bracket on Frame	2	1-1/4" apart
Setback from Frame Face -		1-1/2"

### **Top Jamb (Push Side)**

<b>Component</b>	<b>Hole Count</b>	<b>Hole Spacing</b>
Closer Body (Frame)	4	1-1/2" x 3-1/4"
Arm Shoe (Door)	2	1-1/4" apart

### **Notes:**

- Always verify manufacturer templates.
- Fire-rated doors require through-bolts or sex nuts.
- Measurements taken from hinge side of door.